

# CABINS, ABLUTIONS AND SITE OFFICE CONTAINER

RWSI007 Safety Instruction Royal Wolf Australia and New Zealand. Version 1 April 2016 Page 1 of 1

## SPECIFICATIONS

**Size:** 20' or 40'

**Type:** Cabins, ablutions, camp rec rooms, diner complex, site office, first aid, change room, and lunch rooms

## SAFETY PRECAUTIONS

### Before using the equipment

- Ensure that the equipment is the correct type for the intended use
- Ensure that you have been given a physical demonstration on the correct use of this equipment

### Entry into the container

- Keep hands and fingers away from door and shutter jams to prevent crush injuries if doors move unexpectedly
- Exercise caution with doors and shutter in windy conditions or if container doors or fittings appear to be damaged use door latch provided on PA doors to secure when opened

### Personal Protective Equipment (PPE)



- Wear gloves, eye wear and non-slip footwear

### Site Preparation and Setup

- Maintain a safe distance from delivery vehicles. Do not stand under a suspended load, or, between the moving container and an adjacent object
- Set the container down in an area safe from passing traffic and onto stable, level ground (this will help avoid the door end from twisting, which can make doors difficult to operate after loading)
- If the container floor level is more than 300mm above ground level, ensure a

compliant step or landing is installed for safe access

- Ensure the area is clear of bystanders and there is enough room to safely swing open the doors and shutters

### Using shutters (where fitted)

- Position yourself in front of the shutter and unlock the external pad bolt. Use caution as the internal spring bolts may have unlocked in transit and flip open
- Open windows from the inside and release the spring bolts (usually two fitted) internally to shutter, use caution as the shutter will open automatically outwards and vertically. Ensure this action does not result in striking a person walking in close proximity
- Where a container is to be stacked, ensure that a process has been determined (this may be site specific) to ensure the external pad bolt is accessible in order to open the shutters

### Plumbing Connection

(Where applicable)

- Any plumbing connection must be undertaken by a licensed plumber
- Prior to any transportation, all pipes must be flushed clean and capped

### Electrical Connection

- Ensure 15amp 240V power supply and lead is used for main connection to 15A caravan inlet located in A/C recess (when fitted)
- Any hardwire connection must be undertaken by a licensed electrical contractor
- Ensure leads are protected from damage. Use cable covers at ground level or elevate lead above ground

level. Keep lead away from wet surfaces or standing water

- Ensure electrical switchboard and all electrical leads are test and tagged by licensed electrical contractor

### Closing Doors and Shutters

- Ensure no persons are inside the container prior to closing and locking the doors

### Setting up and Operating Standard Inclusions

- Always refer back to Operator's Manual for the correct use and operation of fixtures
- Conduct a visual inspection of all leads on all appliances. Ensure electrical testing and tagging is current
- Use caution when operating the boiling water system, if installed

### TRANSPORT

Ensure a pad bolt is fitted to every door/ shutter, and any accessories inside the container are secured for transport.

### YOUR RESPONSIBILITY

If you are unsure about the capability or functions of this equipment, or are in doubt about how to use or maintain it correctly, please contact Royal Wolf and we can answer any questions in regards to the safe operations of this equipment.

### FAULTS

In the event you are concerned that the equipment is not working correctly, or may be faulty, please contact Royal Wolf immediately.

For your nearest Royal Wolf branch call:

Australia 1300 037 686

New Zealand 0800 661 241

YOU CAN DO ANYTHING IN A ROYAL WOLF

